

UNIDEN UBC370

Set up Frequency:

- **Step 1.** Set [MODE] to *Scanner* and set [TIME] to *Clock*.
- **Step 2.** Press [HOLD]
- **Step 3.** Select a *Channel Number*.
- This would be the channel number you would like to store the frequency.
- **Step 4.** Press [HOLD]
- **Step 5.** Press [E]
- **Step 6.** Enter the frequency of The Suffah Institute 461.000. Use the keypad to enter the frequency into the radio.
- **Step 7.** Press [E]
- Now the frequency has been stored.



Set up Name for Frequency:

- **Step 1. Press [E/PGM]**
To enter the Program mode (the scanner turns on the PGM icon).
- **Step 2. Press [SEARCH/FM1]**
To enter NAME input mode.
- **Step 3. Press [▲ or ▼]**
To select characters. Press 4 to move cursor to the left, and 6 to move cursor to the right.
- **Step 4. [Press E/PGM]**
To store in the channel memory. Stored name is displayed in HOLD mode or in receiving in SCAN mode.

BAOFENG UV-5R

- **Step 1. Press [VFO/MR] and enter *Frequency Mode*.**
- **Step 2. Press [A/B] and choose the *A Side (upper display)*.**
The A side must be used to program channels into the radio. Programming data entered on the B Side (lower display) will not be saved.
- **Step 3. Press [BAND] for the frequency band.**
Toggle [BAND] to choose 136 MHz (VHF) or 470 MHz (UHF).
If the incorrect band is chosen for the frequency entered in Step 5, the radio will cancel the operation.
- **Step 4. Disable TDR (*Dual Watch/Dual Standby*).**
Press [MENU] 7 [MENU] [press up/down arrow keys] OFF [MENU] [EXIT]
It is highly advised to turn TDR off when programming directly from the radio.
- **Step 5. Enter the frequency of The Suffah Institute 461.000**
Use the keypad to enter the frequency into the radio.
- **Step 7. Assign the frequency to a channel.**
[MENU] 27 [MENU] [enter channel number XXX] [MENU] [EXIT]

